

Atlas Medium

The modular Atlas wardrobe and cabinet range offers you three types with the following external dimensions:

- Small: height: 77 cm - depth: 52,5 cm
- Medium: height: 99 cm - depth: 52,5 cm
- Large: height: 186 cm - depth: 56 cm

Frame

- 2 side panels with a front lath, back, bottom and a plinth on the frontside.
- 2 reinforcement laths on the top side and a tabletop.
- The tabletop has rounded corners in double-sided stratified MDF board. Thickness: 24 mm.
- The panels are made of melaminated or veneered (*) chipboard (thickness: 19 mm).
- The panels are joined together by eccentric cams and dowels.
- The back is milled into a groove in the side panels.
- 4 adjustable synthetic glides.

Interior finishing depends on the chosen type

- Fixed or detachable shelves (thickness: 19 mm).
- Vertical panel in the middle.
- Chromium-plated hanging rail of Ø 19 mm.

Doors and drawers depend on the chosen type

- High-quality self-closing hinges, opening up to 135°.
- Metal design handle.
- Removable drawers. The front surface of the drawers is made of melaminated or veneered (*) chipboard (thickness: 19 mm).
- The drawers are installed in the frame by means of metal rails.



Dimensions


Type Medium:

- height: 99 cm
- length:
M1 and M3: 126 cm or 147 cm
M4 and M5: 166 cm (or 194 cm only for M4)
- depth: 52.5 cm

M1: 3 doors, 4 shelves



M3: 2 doors, 6 shelves



M4: 4 doors, 4 shelves



M5: 4 doors, 2 drawers, 2 shelves



Materials and finishing

- Wood: - chipboard (melaminated, beech veneer (*)).
- MDF (stratified).
- Withstands the common cleaning products.

For more information about the **materials, construction and maintenance**: please consult our material lists.

Options

- Finishing in veneer.
- Cylinder lock.
- Built-in steel safe with cylinder lock.
- 4 hidden castors Ø 50 mm.

Colours

We would like to refer to our extensive colour gamut.
Sample card + samples available on request.

(*) Option

