

Quadra Care

10491 The Quadra Care low is a very compact bedside table with a contemporary and rigid design.

Low model (storage cabinet, drawer)

- 2 side panels with back, bottom, and tabletop.
- Made of melaminated chipboard (thickness 19 mm).
- The side panels, the top of the storage cabinet and the bottom are connected to each other by means of wooden dowels. Then cold glue is used to create a strong cupboard frame.
- The tabletop is connected to the cabinet by means of eccentric cams.
- Storage cabinet with a removable shelf.
- High-quality self-closing hinges, opening up to 175°.
- Metal design handle.
- The removable drawer is made of metal sides, between which a wooden bottom and back have been attached.
- The drawer is installed in the cupboard frame by means of high-quality steel rails with an end stop.
- The metal parts are protected by an epoxy-coating.
- The tabletop is made out of a double sided melaminated chipboard of 19 mm.
- Edges out of PVC.
- 4 adjustable glides.



Dimension

10491 | 42,5 x 43 x height 62,5 cm



Materials and finishing

- Wood: chipboard (melaminated).
- Metal: epoxy-coating (clear gray).
- High-quality self-closing hinges.
- Withstands the common cleaning products.

For more information about the **materials, construction and maintenance**: please consult our material lists.

Options

- Finishing in veneer.
- Tabletop in stratified chipboard.
- Telephone holder.
- 4 hidden castors.

Colours

We would like to refer to our extensive colour gamut.
Sample card + samples available on request.

Handles

- Open handle
- Closed handle

