

# Quadra Small

The Quadra Small cabinet fits in seamlessly with the modular Quadra cabinet range. The width is variable and is determined by the selected version type.

## Frame

- 2 side panels with a front lath, back, bottom and a plinth on the front and backside.
- 2 reinforcement laths on the top side and a tabletop.
- The tabletop has rounded corners in double-sided stratified MDF board. Thickness: 24 mm.
- The panels are made of melaminated or veneered (\*) chipboard (thickness: 19 mm).
- The panels are joined together by eccentric cams and dowels.
- The back is milled into a groove in the side panels.
- 4 adjustable synthetic glides.

## Interior finishing depends on the chosen type

- Fixed or detachable shelves (thickness: 19 mm) (only model S1).

## Doors and drawers depend on the chosen type

- High-quality self-closing hinges, opening up to 170° (only model S1).
- Metal design handle.
- Removable drawers. The front surface of the drawers is made of melaminated or veneered (\*) chipboard (thickness: 19 mm).
- The drawers are installed in the frame by means of metal rails.

## Colours

We would like to refer to our extensive colour gamut.  
Sample card + samples available on request.


(\*) Option

## Dimension


### Model Small:

- height: 77 cm
- length: 66 cm, 86 cm (or 100 cm for model S1)
- depth: 52.5 cm

### S1: 2 doors, 1 shelf



### S2: 3 drawers



## Materials and finishing

- Wood: - chipboard (melaminated, beech veneer (\*)).  
- MDF (stratified).
- Withstands the common cleaning products.

For more information about the **materials, construction and maintenance**: please consult our material lists.

## Options

- Finishing in veneer.
- Cylinder lock.
- 4 hidden castors Ø 50 mm.

